

Quality Checklist : L1 unit

Date: _____

Unit / Robot: _____ Operator: _____ QC: _____

#	ITEM	DESCRIPTION	OP	QC
3	Application of torque in the direction of fixed edge		☐	☐
6	Use of jig for the rack gear alignment		☐	☐
7	Pocket on the base oriented on the rack gear side		☐	☐
8	Addition of pin during the assembly of gear and gearbox		☐	☐
9	Orientation of the gearbox grub screw and the L1 motor mounting plate		☐	☐
10	Addition of base studs before mounting the stud mounting plate		☐	☐
11	Marking after application of torque		☐	☐
12	Addition of cap on the L1 linear guides after application of cap		☐	☐
16	All parts gave been applied		☐	☐
17	The safety net connection plate assy		☐	☐
18	White spacer locations are correct 		☐	☐
19	From the motor side, Thick block on the right side and thin on left		☐	☐
20	Torque markings on the bolts		☐	☐

Unit / Robot: _____

Operator: _____

QC: _____

#	ITEM	DESCRIPTION	OP	QC
4	111		☐	☐
5	222		☐	☐

Unit / Robot: _____

Operator: _____

QC: _____

#	ITEM	DESCRIPTION	OP	QC
13	Check whether the cable cables match on the each side	L3 aise and L1-L2 side	☐	☐
14	Check the cable ties on the bracket. Remove the bracket if not there.		☐	☐
15	Make sure the bracket attached on the L3 side		☐	☐

Quality Checklist : **L3 cable carrier**

Date: _____

Unit / Robot: _____ Operator: _____ QC: _____

#	ITEM	DESCRIPTION	OP	QC
21	Cables are free on the both sides		☐	☐
22	16mm hose is passing behind the fat cables		☐	☐
23	The hose is connected to L2 hose with the two L joints not one		☐	☐
24	Cables and hose are fixed with cable ties except at the middle		☐	☐
25	From arm side, fat cables are top-top then bottom-bottom.		☐	☐
26	From arm side, thin cables are bottom-bottom then top-top.		☐	☐
27	For the electronic box on the right side, cables should be free and passing from the top of the L3 cable carrier mounting bracket.		☐	☐
28	All the cables are fixed by the partition connector		☐	☐
29	The cable ties are cut cleanly without any part left outside the cable carrier head		☐	☐

Unit / Robot: _____

Operator: _____

QC: _____

#	ITEM	DESCRIPTION	OP	QC
30	The orientation of the gearbox grub screw on the right side from front.		☐	☐
31	The L3 belt is attached to the arm side plate with screws.		☐	☐
32	The belt tension is set to: --Nm		☐	☐
33	Electronics box brackets orientation		☐	☐

Quality Checklist : **L2_pillar**

Date: _____

Unit / Robot: _____ Operator: _____ QC: _____

#	ITEM	DESCRIPTION	OP	QC
34	Orientation of the gearbox mounting base		☐	☐
35	The strip orientation		☐	☐
36	Gurb screw locations on the strips		☐	☐
37	Orientation of the gearbox mounted on the pillar		☐	☐
38	The M5 and M6 threads on the top are perfect		☐	☐
39	The eye bolts are added without the nut		☐	☐
40	The eye bolts are fixed		☐	☐
41	Markings are done after the application of torque		☐	☐
42	The linearguide caps are closed after the application of toque		☐	☐

Unit / Robot: _____

Operator: _____

QC: _____

#	PART #	DESCRIPTION	QTY	TOOL	OP
1	—	111	x—	—	☐
2	—	222	x—	—	☐
3	—	333	x—	—	☐
4	—	444	x—	—	☐
5	—	555	x—	—	☐